


Weather optimize function overview

1) The EG4 18kPV now have a **Weather Optimize** function. Once configured, it will automatically optimize battery charging based on tomorrow's local weather condition. If a heavy rain is expected to approach tomorrow, the battery will be automatically charged to the preset SOC in advance.





2) Please add a device first. The weather optimize function will take effect within the time period you set. The server will upload setting instructions to the inverter starting from 17:00 to 20:00 every day. If you want your settings to take effect as soon as possible, please complete them before 17:00. If you set the heavy rain to 100, inverter will enter the charge mode within the set time period, and the charging will not stop until the SOC reaches 100 or the time reaches the end.


d device		
* Serial number	Serial number	
* Charge Start Time	00:30	~
* Charge End Time	04:00	~
Charge percent(%)	by weather:	
* Clear sky	30	
* Few(11%-25%) clouds	65	
cattered(25%-50%) clouds	75	
Broken(51%-84%) clouds	85	
vercast(85%-100%) clouds	95	
* Light rain	80	
* Moderate rain	90	
* Heavy rain	100	
* Other	90	

Cancel

Add




3) After the device is added, you need to set the location of the device. The weather optimize function will not work unless you set the location of the device.





4) Please select or search for local location coordinates in the map. After the update, the device will charge according to the preset logic.





5) After the device is added, the corresponding end user can also see the weather optimize interface in their account, and the end user can modify the charging logic according to their needs.

